Finding your printer's IP address

1. Press the menu button on your Kyocera printer.

Menu Button

2. Press up or down buttons until you see "Report Print."

Up/Down Buttons

3. Press "right" button. Then press "down" button until you see "Status" page.

Right/Down Buttons

4. Press "OK" button twice.

OK Button

5. On the page that prints out, locate your printer's IP address.

Your printer's IP Address will be a series of numbers like: 10.66.20.xxx